



WiFi Channel Setting


1. เปิด Browser (Chrome, Firefox, IE) พิมพ์ **192.168.1.1** ในช่อง Address แล้วกด **Enter**
2. ใส่ Username และ Password โดยดูจากข้อมูลด้านล่างของเราเตอร์



3. หน้า Home คลิก **Local Network**



4. คลิกเลือก WLAN -> WLAN Basic -> WLAN Global Configuration



Home Topology Internet Local Network Management & Diagnosis

Status
WLAN
LAN
Routing
FTP
UPnP
DMS
Samba Service
DNS

WLAN Basic WLAN Advanced WPS WLAN Radar

Page Information
This page provides the function of WLAN basic parameter(s) configuration.

▶ WLAN On/Off Configuration


▼ WLAN Global Configuration

▼ 2.4GHz

Channel: Auto
Auto Channel: Thailand Standard(Recommend: Ch.1-11) Customize
Mode: Mixed (802.11b/g/n/ax)
Band Width: Auto
SGI: On Off
Beacon Interval: 100 ms
Transmitting Power: 100%

Apply Cancel

5. ทำการตั้งค่า WiFi Channel ทั้ง 2.4GHz และ 5GHz โดย Default แล้วจะเป็น Auto



▼ WLAN Global Configuration

▼ 2.4GHz

Channel: Auto
Auto Channel: Thailand Standard(Recommend: Ch.1-11) Customize
Mode: Mixed (802.11b/g/n/ax)
Band Width: Auto
SGI: On Off
Beacon Interval: 100 ms
Transmitting Power: 100%

Apply Cancel

▼ WLAN Global Configuration

▶ 2.4GHz

▼ 5GHz

Channel	Auto
Auto Channel	<input checked="" type="radio"/> Thailand Standard(Recommend: Ch.36-64 and Ch.149-161) <input type="radio"/> Customize
Mode	Mixed (802.11a/n/ac/ax)
Band Width	Auto
S/GI	<input checked="" type="radio"/> On <input type="radio"/> Off
Beacon Interval	100 ms
Transmitting Power	100%

Apply Cancel