



## ตั้งค่า DDNS VDSL Fibrehome HG180


1. เปิด Browser และในช่อง Address พิมพ์ 192.168.1.1 จะแสดงหน้าต่างให้ใส่ User/Pass ให้คลิกที่ปุ่ม Login
2. Password: aisadmin



3. เลือกไปที่ Application คลิก DNS และเลือก Dynamic DNS
  - 3.1 Enable ตีถูกเพื่อเปิดใช้งาน และคลิก Apply
  - 3.2 คลิก Add เพื่อตั้งค่า Domain DDNS



4. เลือก Provider ที่ DDNS Sever
  - 4.1 Oray.com
  - 4.2 Dydns.org
  - 4.3 TZO
  - 4.4 No IP



5. ระบุข้อมูล DDNS

5.1 Host Name ระบุ Host ที่สมัครไว้เช่น aisfibre.dyndns.org


5.2 WAN Connection เลือก Profile aisfibre\_ipv4\_pppoe

5.3 Username

5.4 Password

ระบุ Username+Password ที่สมัครไว้กับ Provider

5.5 เมื่อตั้งค่าเรียบร้อยแล้วกด Apply เพื่อ Save ค่า



The screenshot shows a web interface for configuring DDNS. On the left is a navigation menu with 'Dynamic DNS' selected. The main area contains the following fields:

- DDNS Server: A dropdown menu set to 'DynDNS.org'.
- Host Name: An empty text input field.
- WAN Connection: A dropdown menu set to 'aisfibre\_ipv4\_pppoe'.
- User Name: An empty text input field.
- Password: A text input field with masked characters (dots).
- Buttons: 'Back' and 'Apply' buttons at the bottom.

Red boxes and arrows highlight the Host Name, User Name, Password, and Back/Apply buttons.